

Palm Injection Methodology Using QUIK-jet®

STEP 1

Measure trunk DBH" to determine dosage.



STEP 2

At trunk height of 24"-48", drill 1/3 of trunk diameter or 4 inches into palm (whichever is less).



Use a 3/8" drill bit when using the #4 Arborplug® and 9/32" drill bit when using the #3 Arborplug.

STEP 3

After drilling, disinfect drill bit with isopropyl alcohol or bleach solution.



STEP 4

Using the plug setting tool and hammer, tap plug into trunk until tip of plug is flush with the trunk surface.



Plug slightly deeper than flush (1/16").

STEP 5

Pierce the Arborplug with the needle on QUIK-jet device. Using even pressure, depress plunger on device until all formulation has been injected.



Note: Only inject as quickly as the palm can absorb product. Some palm species may be difficult to inject after significant rainfall or irrigation.

Regardless of chosen formulation, please be sure to follow all label instructions for rates and safety procedures.